

ARTIFICIAL STONE BASIN INSTALLATION INSTRUCTIONS

Important Information

- Prior to Installation it is important to inspect the basin to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation & advise supplier immediately.
- ECT or your supplier will not be liable for the cost of installation or removal of your basin, and warranty will be voided if damage has occurred during or after installation.
- It is recommended that a licensed tradesperson install the basin.

Installation

1. Use the basin as a guide to mark the bench top for the tap and waste outlet positions. Cut out the required shape, allow room for the waste back nut and tapware to be accessible from underneath.
2. Install waste to the basin, do not over tighten it. It will put stress on basin, and may crack the basin.
3. Place the basin in position and fix using neutral cure, mildew resistant, sanitary grade silicone. Clean away excess silicone from around the basin. Use of epoxy two part adhesives will void warranty.

Cleaning & Care

- Wipe with a clean, soft cloth and mild soapy water or nonabrasive bathroom cleaner. Test in an inconspicuous area before cleaning the whole basin.
- Avoid placing hot objects, such as hair straighteners, on any surface as these will cause discolouration and marking.
- Spills of hair dye, after-shave lotion, nail polish and remover, aerosol spray and other harsh chemicals should be removed immediately to prevent damage and discolouration. Clean immediately with mild soapy water using a clean, soft cloth.