



HEAD OFFICE:
42 Castro Way.
Derrimut Vic 3026
ABN: 70 095 343 123
Tel: 03 8390 6300 Fax: 03 8390 6366
EMAIL: ect_sales@outlook.com Website: www.zenmo.com.au

MIRROR 600/750/900/1200 INSTALLATION INSTRUCTIONS

IMPORTANT

Prior to installation it is important to inspect the shaving cabinet to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with the installation and advise supplier immediately. No warranty claim for damage will be accepted if the shaving cabinet is installed. This includes scratches to the glass.

Prior to installation check wall/tile surface where shaving cabinet will be fitted is clean and level.

It is recommended that the mirror is protected during installation.

PLEASE NOTE: MANUFACTURER WILL NOT BE LIABLE FOR THE COST OF INSTALLATION OR REMOVAL OF THE MIRROR & THE WARRANTY WILL BE VOIDED IF DAMAGE OCCURRED DURING INSTALLATION.

Install a mirrored shaving cabinet by marking its position, finding wall studs, and securing it directly through the backboard using screws and wall anchors. For surface mounting, fix it directly to studs; for recessed, install it between studs. Ensure it is level, sealed with silicone, and that doors are adjusted.

Installation Steps

Preparation:

Start by placing the cabinet on a flat, soft surface. If your cabinet has an external open shelf, ensure it is properly attached to the carcass before mounting.

Marking & Levelling:

Hold the cabinet carcass against the wall in your desired position. Use a spirit level to ensure it is perfectly straight and mark all four corners.

Locating Studs:

Use a stud finder to locate support beams within your marked outline. Mark these stud positions on the back panel of your cabinet to ensure you're screwing into solid timber.

Drilling:

In Cabinet:

Pre-drill pilot holes through the back of the cabinet that align with your stud marks.

On Wall: If installing on tiles, use a specialized masonry drill bit to avoid cracking the surface.

Securing:

Surface Mount:

Position the cabinet and drive appropriate screws or bolts through the pilot holes into the wall studs or hollow wall anchors.

Shelves & Doors:

Adjust the hinges to ensure they sit level and close smoothly. Insert shelf pins into the pre-drilled holes at your preferred heights and snap the shelves into place.

Sealing:

Apply non-acidic silicone to all edges where the cabinet meets the wall to prevent water penetration and moisture damage.